



Battery Pack Installation Guide

How to fit your new battery pack to your HSL Clever Comfort™ chair or sofa

What's in the Box?

- 1 x battery pack with 2 leads attached
- Additional box containing an adaptor lead (**Not required for all models**)



Inner Box
Containing
Adaptor Lead

Battery
Charging Lead

Rechargeable
Battery Pack

Battery to
Furniture Lead

Battery Pack Charging Instructions


Before fitting your new battery, ensure it is fully charged.

1. Connect the Battery Pack to the charger using the correct port.
2. Plug the charger into a wall outlet; LEDs will blink while charging.
3. When fully charged, all LEDs stay solid. First charge may take 2–5 hours.
4. Unplug the charger from the wall, then disconnect it from the Power Pack.
5. Connect the Power Pack to the furniture power drive.

See overleaf for set up instructions

- **Lead from Furniture**

- **Battery to Furniture Lead**



Locate the **Battery to Furniture Lead** and connect to the power lead coming from the furniture which is located at the rear underside.

Note: you may need to add the adaptor lead for the correct fitting.



The lights will illuminate to show that the furniture is connected to the battery pack and will also indicate how much charge is left in the battery pack.



Contact our friendly Customer Care Team for any support in setting up your Battery Pack.

Call **01924 507050** Visit **hslchairs.com**